

PR-X seat system

Adjustment of the Prijon PR-X seat system to the paddler



Behind the backrest you find the hex key, which can be used for adjusting the thigh braces and the footplate. The hex key can always remain and be fixed in the dedicated loop, to have it at one's fingertips at any time.

Position of seat

Ex works, the foam seat is fixed in the centered position. A relocation to the front or the rear is possible. Smaller/lighter paddler can fix the seat in the front position, taller/heavier paddlers use the rear position. Please act as follows to change the position of the seat:



1. Grab under the front side of the seat with both hands and loosen the seat carefully and slowly from the Velcro on the floor.



2. Then grab with both hands under the rear side of the seat and loosen it carefully from the Velcro.



3. One hand grabs the seat from the front and one from the rear, then lift it up. Now you position it at the desired place, press it down and sit in the boat.

Footplate (FP)

By loosening the knurled nuts, you can adjust the footplate to your individual length. Then you adjust the width of the footplate, so that it abuts on the hull of the boat.



1. The width of the FP can be individually adjusted.



2. Use the hex key to loosen the screw in the center of the FP. Adapt the width to the desired position of the FP, tighten the screw again.



3. If necessary cut the foam.



Thigh braces

By using the hex key, which sits behind the backrest, you can adjust the thigh brace. It can be moved to the inside or the outside, as well as relocated further to the front or closer to the paddler.



To move the thigh brace to the outside or inside, loosen both screws next to the cockpit rim. Pull or push the thigh brace to the desired position and tighten the screws again.



To relocate the thigh brace to the front or the rear, undo both screws completely, so that you can take off the thigh brace. Then slip with one hand between the plastic shell and the foam to take the nuts out of the groove and move them into a new position, analog to the position of the screws.

Nuts closer to the paddler = thigh braces move further afar



When inserting the thigh brace again, pay attention to both screws interlocking with the nuts, which are sitting staggered in the plastic shell.

Backrest

The backrest is tensioned by the rubber bands in the rear and the ratchets in front.



Tension the backrest with the ratchets.



To release the tension, push the black lever to the rear.



To be able to store equipment or to place the float bag behind the seat, unhook the rubber bands.